



**ZYB.....A Series
Oil-lubricant
Vacuum & Pressure
Combined Vacuum Pump**


Operation Instruction

1.Application

Model ZYB sliding—vane vacuum / Pressure pump is an indispensable part of the modern printing machinery. In the case of suction vacuum $\geq -60\text{kPa}$, supplement vacuum $\geq -20\text{kPa}$ and pressure $\leq 60\text{kPa}$, it can be used for suction, supplement and blow simultaneously. mainly for the paper transport or paper receipt mechanism of fullsize or folio printer. and for other machines that need vacuum or pressure.

2.Construction

The pump consists of body, base, cooling air system, oil—air separating system and lubricating system. It is equipped with wear—proof fittings between vane and body, so as to—prolong the service life. The cooling air system ensures the whole—pump good cooling effect and the oil—air separating system—a purified compressed air.



- | | |
|-----------------------------------|---------------------------------|
| 1. Filling plug | 2. Vacuum regulating Valve knob |
| 3. Suction nipple | 4. Top cage |
| 5. Supplement nipple | 6. Compression nipple |
| 7. pressure regulating valve knob | 8. Reservoir cover |
| 9. Cap Screw | 10. Supplement filter |
| 11. Main suction filter | 12. Front Cover |
| 13. Rear cover | |

Specifications:-

Model		ZYB-40A	ZYB-60A	ZYB-80A	ZYB-130A
Displacement :	(m ³ /h)	40	60	80	130
Rated Suction Vacuum :	kPa	-60	-60	-60	-60
	(mmHg)	(456)	(456)	(456)	(456)
Rated Supplement Vacuum :	kPa	-20	-20	-20	-35
	(mmHg)	(152)	(152)	(152)	(266)
Rated Pressure :	kPa	60	60	60	60
	(kgf/cm ²)	(0.6)	(0.6)	(0.6)	(0.6)
Temperature :	(°C)	50	55	65	85
Outside Dia. Of Inlet & Outlet :	(mm)	∅27	∅27	∅34	G½ G1½ G1½
Overall Dimension :	(mm)	865 x 328 x 340	910 x 373 x 380	970 x 373 x 380	1213 x 407 x 450
Weight :	(kg)	85	105	120	210
Type Of Motor :		Y90L-4 IM B ₅	Y100L-4 IM B ₅	Y100L-4 IM B ₅	Y132S-4 IM B ₈
Speed :	(rpm)	1400	1420	1420	1440
Motor Power :	(kW)	1.5	2.2	3.0	5.5

3. Operation and Maintenance

1. The air pump should be set in a clean, cool and ventilating place, It must be placed horizon tally without any inclination.

2. Connect one end of the suction pipe to Nipple(3) and the other to paper transporting unit. Connect one end of the supplement pipe to Nipple(5) and the other to paper receiving unit. Connect the compression pipe to Nipple.(6).

3. The direction of pump rotation: Upon turning on the motor, observe if the direction is accordance with that of the arrow on the indicating plate.

4. Before starting a new pump, remove the plug(1) and pour in the filtered lubricant, and check the oil level at least once a month.

5. The lubrication of the pump is accomplished by an oil pump when the oil-contained compressed air passes the oil-separator in the base, the lubricant is condensed and sent back to the oil tank.

6. Change or lubricant:

The oil tank should be cleaned and the oil changed after an initial running of 300 hours and then changed once every 300 running hours:

7. Lubricant:

The lubricant for this pump is China-made No.19 compressor oil or other lubricants having the properties listed below

(1) Relative viscosity: -22° E50 or 320mm² / s

(2) Flash point: 240°C

(3) Condensation point: 15°C

8. Air filter clean:

Undo the cap screw(9), remove the cover(8), then take out the filter(11) and (10), wipe out the dirt on surface with a brush and wash away the oil dirt. If the filtering wool or paper pith is found damaged, it should be replaced. The filter is preferable to be cleaned in a period of every one to two months.

9. Oil-air separator sieve clean:

The separation of lubricant from the compressed air is acquired by the four oil-air separation sieves in the base. These sieves should be cleaned at least once every year. To clean them, untight the front cover(12) and rear cover(13) of the pump, take out the sieves and clean them in petrol.

10. Regulating valve:

These two regulating valves are limited to their rated load value before delivery. In case the valve are discovered not up to the rated ones after long period operation or overhaul, take off the knob(2) or (7), unscrew the set-screw on the brass ring, turn the adjusting screw at the middle by means of a turning clockwise and decrease the other way-round.

11. The rubber ring of flexible coupling should be checked at least every half a year. Replace it once a breakage is found. When replacing, first remove the motor, then take off the clips on the pins of the rubber ring, and the rubber ring is ready to come off. See to it that there is a play about 1-2mm between the two half couplings when remounting. You can observe it through the square hole of the motor connecting frame, and under no circumstances should these ends touch each other.

12. Cooling system clean:

The dirt on cooling pipes should be cleaned every half a year. Upon removing the top cage(4), most of the dirt visible can be cleaned. Then, while the pump is running, clean the rest by blowing with compressed air and the dirt will be brought out from the vent of the cooling fan.